

# SIMPLEBLOCK.PV

## RAIL-LESS MOUNTING SYSTEM FOR STANDING SEAM ROOFS

# INSTALLATION GUIDE

**REVISION DATE:** 12/09/20

VERSION: v1.3

INSTALLATION GUIDE

For Installers. By Installers.

VERSION: v1.3

REVISION DATE: 12/9/20

Clicking the page name will take you to that page

TABLE OF CONTENTS	PAGE 01
FEATURES & BENEFITS	PAGE 02
INSTALLER INFO	PAGE 03
COMPONENTS	PAGE 04
RATINGS	PAGE 05
	PAGE 06
INSTALLATION	PAGE 00
LAYUUI	PAGE 11
GROUNDING	PAGE 12
MODULE LIST	PAGE 16

#### INSTALLATION GUIDE

## EcoFasten

VERSION: v1.3

**REVISION DATE: 12/9/20** 



### SIMPLEBLOCK-PV

SimpleBlock-PV is an innovative UL 2703 listed rail-less racking system that utilizes EcoFasten end spacers and integrated bonding mid clamps for use on standing seam metal roofs. The block utilizes pre-installed oval-point set screws for a fast installation that does not require penetrating the roof.

#### **FEATURES**

- Integrated bonding
- Two pre-installed oval-point set screws for fast installation
- No roof penetrations required
- North-South adjustability

## For Installers. By Installers.

VERSION: v1.3

**REVISION DATE: 12/9/20** 

### **ADDITIONAL INSTALLER INFORMATION**

The capacity of the SimpleBlock clamp is dependent on the roofing material and type to which it is fastened. The roofing type and material used in tests is noted in SimpleBlock Ultimate Capacity Laboratory Test. Appropriate factors of safety should be determined and applied by the design professional or qualified personnel to the noted ultimate values based on the specific circumstance and application, but under NO circumstance should the factor of safety be less than 2. The metal roofing must be adequately attached to the supporting roof system/structure to resist loads. The loads applied to the SimpleBlock clamp will be transferred to the roofing material and supporting members. Said roofing material and supporting members and their attachments must be designed or analyzed accordingly. The SimpleBlock is NOT approved for use as a fall restraint device.

For more information refer to SimpleBlock Ultimate Capacity Laboratory Test Results on our web page.

Please Note: Review module and any 3<sup>RD</sup> party manufacturer's documentation for compatibility and compliance with warranty terms and conditions.

SYSTEM COMPONENTS REQUIRED

**INSTALLATION GUIDE** 

#### SIMPLEBLOCK-PV:

- 1. Mid-Clamp
- 2. Hardware
- 3. Mount

#### **ADDITIONAL REQUIRED COMPONENTS:**

**REVISION DATE: 12/9/20** 

🕸 EcoFasten

For Installers, By Installers,

VERSION: v1.3

- 4. Coupling
- 5. End Spacer



#### **ACCESSORIES**



#### **ROCKIT CLIP 2.0**







#### **AVAILABLE END SPACER HEIGHTS**



32MM







35MM





40MM

REVISION DATE: 12/9/20 VERSION: v1.3

#### INSTALLATION GUIDE

#### EcoFasten For Installers. By Installers.

Class A Fire Ratings	Type 1, 2 & 3*
Max System Voltage	1500
Max Fuse Rating	30A
Certification	Conforms to UL STD 2703
Markings	Product listing label is located on SR-X End Spacer
Roof Pitch	1/2:12 - 12:12
UL 2703 Allowable Design Load Rating	30 psf downward, 30 psf upward and 5 psf lateral
Max Module Size	25.6 sq. ft.
Single use Rated Components	SR-X Mid-Clamp
Multiple use Rated Component Position independent	SimpleBlock Coupling
Module Orientation	Landscape Only

\*Class A for Steep Slope & Low Slope Flush-Mount (Symmetrical) Applications when using Type 1, 2 or 3, Listed Photovoltaic Module when installed over non combustible roofs. This product can be installed with any module to roof gap

Certification of Simple Block includes bonding to both painted and galvalume standing seam metal roofs

#### UL 2703 MARKING EXAMPLE:





#### TORQUE SPECIFICATIONS

Component	Torque (in-lb)
SR-X Mid-Clamp	150
SimpleBlock-PV Coupling	150
SimpleBlock-PV Set Screws	150
RockIt Clip 2.0	144

Periodic reinspection of components shall be performed to verify that there is no corrosion detrimental to system strength and electrical conductivity, no loose bolts, and/or other variables that could compromise array safety. Any corroded or damaged components shall be immediately replaced.

INSTALLATION GUIDE

## For Installers. By Installers.

VERSION: v1.3

**REVISION DATE: 12/9/20** 



### SIMPLEBLOCK-PV COMPONENTS

- 1. Mount
- 2. Mid-Clamp
- 3. Set Screws
- 4. End Spacer
- 5. Bolt 0.3125-18x2.5"
- 6. Flange Nut 0.3125-18"

page 06

INSTALLATION GUIDE

## For Installers. By Installers.

VERSION: v1.3

REVISION DATE: 12/9/20



#### SIMPLEBLOCK-PV COUPLING COMPONENTS

- 1. MLPE-Clip
- 2. Mid-Clamp
- 3. Flange Nut 0.3125-18"
- 4. Bolt .3125-18x2.5"

PAGE

 $\cap$ 

INSTALLATION GUIDE

#### EcoFasten For Installers, By Installers,

VERSION: v1.3

**REVISION DATE: 12/9/20** 



#### **INSTRUCTIONS**

- - 1. Determine appropriate array location
  - 2. Select first row positioning for the mounts
- Mark next row of attachments and repeat for remaining rows

 3.A Your North-South measurement equals the module width +1/2" to accommodate for the module gap

4. Locate first seam closest to array edge (inside array footprint) and mark

 Find next seam for attachment base on appropriate span and continue marking to end of array.

6. Span

7. Mark each attachment point for array on seams.

**NOTE:** Modules must be installed in landscape orientation only.

REVISION DATE: 12/9/20 VERSION: v1.3

#### INSTALLATION GUIDE

## For Installers. By Installers.

#### SIMPLEBLOCK INSTALLATION





#### INSTALL SIMPLEBLOCK TO STANDING SEAM METAL ROOF

- Tighten set screws to 150 in-lbs using a 3/8" Allen head bit.
- Determine the location of the next row of clamps. Clamp spacing can be calculated by adding 1/2" to the width of the module being installed
- Verify that each SimpleBlock mid-clamp has the proper engagement with the standing seam (see step 1)

INSTALLATION GUIDE

#### EcoFasten For Installers. By Installers.

VERSION: v1.3

**REVISION DATE: 12/9/20** 

#### **COUPLING INSTALLATION**



#### INSTALL COUPLING TO CONNECT AND BOND MODULES EAST TO WEST

- Attach coupling to panels by sliding coupling between the two panels and tighten to 150 in-lbs
- Couplings should be placed between each panel East to West.
- Clamp must engage panels for proper bonding path

INSTALLATION GUIDE

# For Installers. By Installers.

VERSION: v1.3

**REVISION DATE: 12/9/20** 

#### **TYPICAL ARRAY LAYOUT**



SimpleBlock without SR-X End Spacers

SimpleBlock Couplings

INSTALLATION GUIDE

# For Installers. By Installers.

VERSION: v1.3

**REVISION DATE: 12/9/20** 

#### **GROUNDING LUG INSTALLATION**



Install ground lug on the module per ground lug and module manufacturer's instructions

#### **NECESSARY COMPONENTS:**

One of the following ground lugs (or any UL 2703 compliant ground lug):

- Burndy CL50-1TN Ground Lug (UL 2703 E3514343 / UL 467-E9999)
- ILSCO SGB-4 Ground Lug (UL 2703 E354420 / UL 467 E34440)
- ILSCO GBL-4DBT(UL2703 E354420 / UL467 E344401)
- ILSCO GBL-4DBTH (UL 2703 E354420 / UL 467 E34440)
- ILSCO GBL-4SS (UL 2703 E354420 I UL 467 E34440)

This system needs to be grounded in accordance with the National Electrical Code, ANSI/NFPA 70.

\*Copper wire should not come in direct contact with aluminum at any point on the array\*

REVISION DATE: 12/9/20 VERSION: v1.3

## EcoFasten

#### **MLPE CLIP ACCESSORY**

INSTALLATION GUIDE



#### **INSTALL MLPE CLIP ACCESSORY:**

- Determine mounting location of the MLPE and MLPE Clip on the module frame.
- Push the nut/bolt of the MLPE Clip so the carriage bolt head is furthest away from the stainless plate.
- Slide the bolt shaft into the slot on the MLPE mounting flange.
- Hold the carriage bolt into the MLPE mounting flange slot with your finger, this will keep the carriage bolt from spinning in the slot. Tighten the nut to 144 in-lbs using a 1/2" hex socket.

#### **MLPE CLIP IS COMPATIBLE WITH:**

- AP SYSTEMS: QS1, YC600
- DARFON: MIG240, MIG300, G320, G640
- ENPHASE: M250-72, 250-60, M215-60, C250-72, S230, S280, IQ 6, IQ 6+, IQ7, IQ 7A, IQ 7+, IQ 7X, Q Aggregator
- SMA: "RoofCommKit-P2-US, TS4-R Module Retrofit Kits (TS4-R-S, TS4-R-O, TS4-R-F)"
- **SOLAREDGE:** M1600, P300, P320, P340, P370, P400, P401, P405, P485, P505, P600, P700, P730, P800p, P800s, P801, P850, P860, P950, P960
- **TIGO:** "Tigo Access Point (TAP), TS4-R-X (where X can be F, M, O, or S), TS4-R-X-DUO (where X can be M, O, or S), TS4-A-X (where X can be F, 2F, O, O-DUO, or S)"
- SEE PAGE 22 FOR COMPATIBLE MODULE LIST

INSTALLATION GUIDE

#### **BONDING ASSEMBLY AND BONDING PATH**



UL 1703 or UL 61730, only when that specific module has been evaluated for mounting and grounding, in compliance with the included installation instructions.

**NOTE:** Grounding lug must be visible to inspectors from the entire perimeter of the PV array.

#### **GROUNDING METHOD**

Each row of modules bonds E-W through the Mid- Clamps and End-Clamps. One approved ground lug is required per row of modules, on short side of module frame.

**REVISION DATE: 12/9/20** 

🖉 EcoFast

VERSION: v1.3

For Installers, By Installers,

**Bond Path** 

INSTALLATION GUIDE

REVISION DATE: 12/9/20 VERSION: v1.3

EcoFasten

For Installers. By Installers.

### **MAINTENANCE JUMPER BONDING PATH**

Routine maintenance of a PV module or mounting system, e.g. inspection or cleaning, shall not involve breaking or disturbing the bonding path of the system. Please see diagram below for ensuring the bond path has not been broken or disturbed prior to conducting any maintenance.



INSTALLATION GUIDE

## MODULE COMPATIBILITY LIST

The SimpleBlock System may be used to ground and/or mount a PV module complying with UL 1703 or UL 61730 only when the specific module has been evaluated for grounding and/or mounting in compliance with the included instructions.

**REVISION DATE: 12/9/20** 

🗳 EcoFasten

For Installers. By Installers.

VERSION: v1.3

Unless otherwise noted, "xxx" refers to the module power rating and both black and silver frames are included in the certification.

MANUFACTURER	LIST OF UL2703 APPROVED MODULES
Adani	Adani modules with 35 and 40mm frames
	ASX-Y-ZZ-xxx
	Where "X" can be B, M or P, "Y" can be 6 or 7, and "ZZ" can be blank, PERC,
	B-PERC, or AB-PERC
	Amerisolar modules with 35, 40 and 50 mm frames
Amorisolar	AS-bYxxxZ
Amerisolai	Where "b" can be 5 or 6; "Y" can be M, P, M27, P27, M30, or P30; and "Z" can
	be blank, W or WB
	Aptos modules with 35 and 40 mm frames
Aptos Solar	DNA-yy-zz23-xxx
	Where "yy" can be 120 or 144; and "zz" can be MF or BF
	Astronergy modules with 30, 35, 40, and 45 mm frames
	aaSMbbyyC/zz-xxx
Astronergy Solar	Where "aa" can be CH or A; "bb" can be 60, 66, or 72; "yy" can be blank, 10
	or 12; "C" can M, P, M(BL), M-HC, M(BL)-HC, P-HC, M(DG), or M(DGT); and
	"zz" can be blank, HV, F-B, or F-BH
	ASUN modules with 35 and 40 mm frames
ΔςιιΝ	ASUN-xxx-YYZZ-aa
AJON	Where "YY" can be 60 or 72; "ZZ" can be M,or MH5; and "aa" can be blank or
	BB
	Auxin modules with 40 mm frames
Auxin	AXN6y6zAxxx
AWAIII	Where "y" can be M or P; "z" can be 08, 09, 10, 11, or 12; and "A" can be F or
	Т
Axitec	Axitec Modules with 35 and 40 mm frames
	AC-xxxY/aaZZb
	Where "Y" can be M, P or MH; "aa" can be blank, 125- or 156-; "ZZ" can be
	54, 60, 72, 120, or 144; "b" can be S, X, V, XV, or MX

INSTALLATION GUIDE

# For Installers. By Installers.

VERSION: v1.3

REVISION DATE: 12/9/20

MANUFACTURER	LIST OF UL2703 APPROVED MODULES
Boviet	Boviet modules with 35 and 40mm frames
	BVM66aaYY-xxxBcc
	Where "aa" can be 9, 10 or 12; "YY" is M or P; and "B" can be blank, L or S;
	and "cc" can be blank, H, H-BF, H-HC, HC-BF or H-HC-BF
	BYD modules with 35 mm frames
RVD	BYDxxxAY-ZZ
	Where "A" can be M6, P6, MH or PH; "Y" can be C or K; and "ZZ" can be 30 or
	36
	Canadian Solar modules with 30, 35 and 40 mm frames
Canadian Solar	CSbY-xxxZ
canadian Solar	Where "b" can be 1, 3 or 6; "Y" can be H, K, L, P, U, V, W, or X; and "Z" can be
	M, P, MS, PX , M-SD, P-AG, P-SD, MB-AG, PB-AG, MS-AG, or MS-SD
	CertainTeed modules with 35 and 40 frames
CertainTeed	CTxxxYZZ-AA
Certainreeu	Where "Y" can be M, P, or HC; "ZZ" can be 00,01, 10, or 11; and "AA" can be
	01, 02, 03, or 04
	Csun modules with 35 and 40 mm frames
CSUN	YYxxx-zzAbb
	Where "YY" is CSUN or SST; "zz" is blank, 60, or 72; and "A" is blank, P or M;
	"bb" is blank, BB, BW, or ROOF
	Dehui modules with 35 and 40mm frames
Dehui	DH-MYYYZ-xxx
	Where "YYY" can be 760, 772, 860, 872; and "Z" can be B or W
	Ecosolargy modules with 35, 40, and 50 mm frames
Ecosolargy	ECOxxxYzzA-bbD
	Where "Y" can be A, H, S, or T; "zz" can be 125 or 156; "A" can be M or P; "bb"
	can be 60 or 72; and "D" can be blank or B
	ET Solar modules with 35, 40, and 50 mm frames
ET Solar	ET-Y6ZZxxxAA
	Where "Y" can be P, L, or M; "ZZ" can be 60 or 72 or 72BH; and "AA" can be
	WB, WW, BB, WBG, WWG, WBAC, WBCO, WWCO, WWBCO or BBAC
	Hex modules with 35, 40, and 50 mm frames
Flex	FXS-XXXYY-ZZ;
	Where "YY" can be BB or BC; and "ZZ" can be MAA1B, MAA1W, MAB1W,
	SAA1B, SAA1W, SAC1B, SAC1W, SAD1W, SBA1B, SBA1W, SBC1B, or SBC1W

<sup>раде</sup>

INSTALLATION GUIDE

# For Installers. By Installers.

VERSION: v1.3

**REVISION DATE: 12/9/20** 

MANUFACTURER	LIST OF UL2703 APPROVED MODULES
GCL	GCL modules with 35 mm and 40 mm frames GCL-ab/YY xxx
	Where "a" can be M or P; "b" can be 3 or 6; and "YY" can be 60, 72, 72H, or 72DH
	Gigawatt modules with 40 mm frames
GigaWatt Solar	GWxxxYY
	Where "YY" can be either PB or MB
	Hansol modules with 35 and 40 frames
Hansol	Where "YV" can be PB_PD_PE_TB_TD_UB_UD_or UE: and "zz" can be AH2
	AN1. AN3. AN4. HH2. HV1. or IH2
	Hanwha Solar modules with 40, 45, and 50 mm frames
Hanwha Solar	HSLaaP6-YY-1-xxxZ
	Where "aa" can be either 60 or 72; "YY" can be PA or PB; and "Z" can be
	blank or B
	Hanwha Q CELLS Modules with 32, 35, 40, and 42mm frames
	aaYY-ZZ-xxx
	where "aa" can be Q. or B.; "YY" can be PLUS, PRO, PEAK, LINE PRO, LINE
	PLUS, PLUS DUO OF PEAK DUO; and "ZZ" can be G3, G3.1, G4, G4.1, L-G2, $C_{2}$
	L-02.5, L-05, L-05.1, L-059, L-04, L-04.2, L-049, L04.2/1AA, DFR-05, DLR-05, RED.G2.1, RIK-G2.1, RED.G4, RED.G4.1, RED.G4.2, RIK-G4.1, G4/SC, G4.1/
Hanwha O CELLS	SC GA 1/TAA GA 1/MAX BER GA 1/TAA BER GA 1/MAX BIK GA 1/TAA BIK
	G4 1/SC EC-G4 4 G5 G5/SC G5/TS BLK-G5 BLK-G5/SC BLK-G5/TS L-G5
	L-G5.1, L-G5.2, L-G5.2/H, L-G5.3, G6, G6/SC, G6/TS, G6+, BLK-G6, L-G6,
	L-G6.1, L-G6.2, L-G6.3, G7, BLK-G6+, BLK-G6+/AC, BLK-G6+/SC, BLK-G6/TS,
	G6+/TS, BLK-G6+/TS, BLK-G7, G7.2, G8, BLK-G8, G8+, BLK-G8+ L-G7, L-G7.1,
	L-G7.2, L-G7.3, L-G8, L-G8.1, L-G8.2, L-G8.3, L-G8.3/BFF, ML-G9, BLK ML-G9,
	ML-G9+, BLK ML-G9+, XL-G9, XL-G9.2 or XL-G9.3
	Heliene modules with 40 mm frames
Heliene	YYZZxxxA
nenene	Where "YY" can be 36, 60, 72, or 96; "ZZ" can be M, P, or MBLK; and "A" can
	be blank, HomePV, or Bifacial
	HI-SAAE modules with 35 and 40 mm frames
HT-SAAE	$M_{\text{More}} = 1002-XXX$
	M(V) = P(V) = C

INSTALLATION GUIDE

## EcoFasten For Installers. By Installers.

VERSION: v1.3

REVISION DATE: 12/9/20

MANUFACTURER	LIST OF UL2703 APPROVED MODULES
Hyundai	Hyundai modules with 33, 35, 40 and 50 mm frames
	HiY-SxxxZZ
	Where "Y" can be A, D, M or S; and "ZZ" can be HG, HI, KI, MI, MF, MG, PI, RI,
	RG, RG(BF), RG(BK), SG, TI, or TG
	Itek Modules with 40 and 50 mm frames
ltek	IT-xxx-YY
	Where "YY" can be blank, HE, or SE, or SE72
	JA Solar modules with 30, 35, 40 and 45 mm frames
	JAyyzz-bbww-xxx/aa
IA Solar	Where "yy" can be M, P, M6 or P6; "zz" can be blank, (K), (L), (R), (V), (BK), (FA),
	(TG), (FA)(R), (L)(BK), (L)(TG), (R)(BK), (R)(TG), (V)(BK), (BK)(TG), or (L)(BK)(TG);
	"bb" can be 48, 60, or 72; "ww" can be D09, S01, S02, S03, S06, S09, S10, or
	S12; and "aa" can be BP, MR, SI, SC, PR, 3BB, 4BB, 4BB/RE, 5BB
	Jinko modules with 35 and 40 mm frames
	JKMYXXXZZ-aa
P., I., .	where "Y" can either be blank or S; "ZZ" can be M, P, or PP; and "aa" can be
Јіпко	DIANK, 60, 60B, 60H, 60L, 60BL, 60HL, 60HB, 60HBL, 6HBL-EP, 60-J4, 60B-
	J4, 60B-EP, 60(PIUS), 60-V, 60-MIX, /RL3-V, /RL3-IV, /2, /2B, /2-J4, /2B-J4,
	/2(Plus), /2-V, /2H-V, /2L-V, /2HL-V, /2-MIX, /2H-BDVP, /2HL-IV, OF /2HL-V-
	Kyocera Modules with 46mm frames
	KYxxxZZ-AA
Kvocera	Where "Y" can be D or U: "ZZ" can be blank. GX. or SX: and "AA" can be LPU.
	LFU, UPU, LPS, LPB, LFB, LFBS, LFB2, LPB2, 3AC, 3BC, 3FC, 4AC, 4BC, 4FC,
	4UC, 5AC, 5BC, 5FC, 5UC, 6BC, 6FC, 8BC, 6MCA, or 6MPA
	LG modules with 35, 40, and 46 mm frames
	LGxxxYaZ-bb
LG	Where "Y" can be A, E, M, N, Q, S; "a" can be 1 or 2; "Z" can be C, K, T, or W;
	and "bb" can be A3, A5, B3, G3, G4, J5, K4, L5, N5, or V5
	Longi modules with 30, 35 and 40 mm frames
Longi	LRa-YYZZ-xxxM
Longi	Where "a" can be 4 or 6; "YY" can be blank, 60 or 72; and "ZZ" can be blank,
	BK, BP, HV, PB, PE, PH, HBD, HIB, HIH, HPB, HPH, or HIBD
	Mission Solar modules with 33 and 40 mm frames
Mission Solar	MSEbbxxxZZaa
MISSION Solar	Where "bb" can be blank or 60A; "ZZ" can be blank, MM, SE, SO, SQ , SR, or
	TS; and "aa" can be blank, 1J, 4J, 4S, 5K, 5T, 60, 6J, 6S, 6W, 8K, 8T, or 9S

REVISION DATE: 12/9/20 VERSION: v1.3

#### INSTALLATION GUIDE

## EcoFasten For Installers. By Installers.

MANUFACTURER	LIST OF UL2703 APPROVED MODULES
Mitsubishi	Mitsubishi modules with 46 mm frames
	PV-MYYxxxZZ
	Where "YY" can be LE or JE; and "ZZ" can be either HD, HD2, or FB
Motech	IM and XS series modules with 40, 45, and 50 mm frames
Novt Eporgy	Next Energy Alliance modules with 35 and 40mm frames
Alliance	yyNEA-xxxZZ
Annunee	where "yy" can be blank or US; "ZZ" can be M, MB or M-60
	Neo Solar Power modules with 35 mm frames
Neo Solar Power	D6YxxxZZaa
	Where "Y" can be M or P; "ZZ" can be B3A, B4A, E3A, E4A, H3A, H4A; and "aa"
	can be blank, (TF), ME or ME (TF)
	Panasonic modules with 35 and 40 mm frames
Panasonic (HIT)	VBHNxxxYYzzA
	Where "YY" can be either KA, RA, SA or ZA; "zz" can be either 01, 02, 03, 04,
	06, 06B, 11, 11B, 15, 15B, 16, 16B, 17, or 18; and "A" can be blank E, G or N
Panasonic	Panasonic modules with 30 mm frames
(EverVolt)	EVPVxxxA
. ,	Where "A" can be blank or K
	Peimar modules with 40 mm frames
Peimar	SDXXXYZZ
	Where "b" can be G, M or P; "Y" can be M or P; and "zz" can be blank, (BF), or
	(FB) Dhiladalahia madulas with 25 and 40 mm frames
Dhiladalahia Calar	Philadelphia modules with 35 and 40 mm frames
Philadelphia Solar	PS-12ZAA-XXX
	Phone Selar modules with 25, 40, and 45 mm frames
	$P(v_{VVV}V_{-77/\Delta})$
Phono Solar	Where "Y" can be M M1 MH or M1H or P: "77" can be $20 \text{ or } 24$ and "A" can
	be E T II or TH
	Recom modules with 35 and 40 mm frames
Recom	RCM-xxx-6vv
	Where "vv" can be MA. MB. MF or MF
	REC modules with 30, 38 and 45 mm frames
REC Solar	RECxxxYYZZ
	Where "YY" can be AA, M, NP, PE, PE72, TP, TP2, TP2M, TP2SM, TP2S or
	TP3M; and "ZZ" can be blank, Black, BLK, BLK2, SLV, or 72

INSTALLATION GUIDE

# For Installers. By Installers.

VERSION: v1.3

**REVISION DATE: 12/9/20** 

MANUFACTURER	LIST OF UL2703 APPROVED MODULES
Renesola	ReneSola modules with 35, 40 and 50 mm frames
	AAxxxY-ZZ
	Where "AA" can be SPM(SLP) or JC; "Y" can be blank, F, M or S; and "ZZ"
	can be blank, Ab, Ab-b, Abh, Abh-b, Abv, Abv-b, Bb, Bb-b, Bbh, Bbh-b, Bbv,
	Bbv-b, Db, Db-b, or 24/Bb
	Renogy Modules with 40 and 50 mm frames
Renogy	RNG-xxxY
	Where "xxx" is the module power rating; and "Y" can be D or P
	Risen Modules with 35 and 40 mm frames
Risen	RSMyy-6-xxxZZ
	Where "yy" can be 60, 72, 120, 132 or 144; and "ZZ" can be M or P
	S-Energy modules with 35 and 40mm frames
	SABB-CCYYY-xxxZ
S-Energy	Where "A" can be C, L or N; "BB" can be blank, 20, 40 or 45; "CC" can be
	blank, 60 or 72; "YYY" can be blank, MAE, MAI, MBE, MBI, MCE or MCI; and
	"Z" can be V, M-10, P-10 or P-15
	Seraphim modules with 35 and 40 mm frames
Seraphim	SEG-aYY-xxxZZ
Energy Group	Where "a" can be blank, 6 or B; "YY" can be blank, MA, MB, PA, or PB; and
	"ZZ" can be blank, BB, BG, BW, HV, WB, WW, BMB, BMA-HV, BMB-HV
	Seraphim modules with 40 and 50 mm frames
Soranhim USA	SRP-xxx-6YY-ZZ
Serapinin USA	Where "xxx" is the module power rating; and "YY" can be MA, MB, PA, PB,
	QA-XX-XX, and QB-XX-XX; ZZ is blank, BB or HV
	Sharp modules with 35 and 40 mm frames
Sharp	NUYYxxx
	Where "YY" can be SA or SC
	Silfab Modules with 38 mm frames
Silfab	SYY-Z-xxxAb
	Where "YY" can be IL, SA, LA, SG or LG; "Z" can be blank, M, P, or X; "A" can
	be blank, B, H, M, N; and "b" can be A, L, G, or T
Salaria	Solaria modules with 40 mm frames
	PowerXT xxxY-ZZ
Sularia	Where "Y" can be R or C; and "ZZ" can be AC, BD, BX, BY, PD, PM, PM-AC, PX,
	PZ, WX or WZ

INSTALLATION GUIDE

# For Installers. By Installers.

VERSION: v1.3

**REVISION DATE: 12/9/20** 

MANUFACTURER	LIST OF UL2703 APPROVED MODULES
Solarcity (Tesla)	Solarcity modules with 40 mm frames
	SCxxxYY
	Where "YY" can be blank, B1 or B2
SolarTech	SolarTech modules with 42 mm frames
	STU-xxxYY
	Where "YY" can be PERC or HJT
	SolarWorld Sunmodule Plus, Protect, Bisun, XL, Bisun XL, may be followed
SolarWorld AG	by mono, poly, duo, black, bk, or clear; modules with 31, 33 or 46 mm
	frames
	SW-xxx
SolarWorld	SolarWorld Sunmodule Plus, Protect, Bisun, XL, Bisun XL, may be followed
Americas	by mono, poly, duo, black, bk, or clear; modules with 33 mm frames
	SWA-XXX Sonali Modulos with 40 mm frames
Sonali	
	Stion Thin film modules with 35 mm frames
Stion	STO-YYY or STO-YYYA
	SunEdison Modules with 35, 40 & 50 mm frames
	SE-Yxxx7ABCDE
SunEdison	Where "Y" can be B. F. H. P. R. or Z: "Z" can be 0 or 4: "A" can be B.C.D.E.H.I
	I.K.L.M. or N : "B" can be B or W: "C" can be A or C: "D" can be 3. 7. 8. or 9:
	and "E" can be 0. 1 or 2
	Suniva modules with 35, 38, 40, 46, and 50 mm frames
	OPTxxx-AA-B-YYY-Z
Suniva	MVXxxx-AA-B-YYY-Z
	Where "AA" is either 60 or 72; "B" is either 4 or 5; "YYY" is either
	100,101,700,1B0, or 1B1; and "Z" is blank or B
	Sunpower standard (G3 or G4) or InvisiMount (G5) 40 and 46 mm frames
	SPR-Zb-xxx-YY
Sunpower	Where "Z" is either A, E, P or X; "b" can be blank, 17, 18, 19, 20, 21, or 22; and
	"YY" can be blank, BLK, COM, C-AC, D-AC, E-AC, BLK-E-AC, G-AC, BLK-C-AC, or
	BLK-D-AC
	Sunspark modules with 40 mm frames
Sunsnark	SYY-xxxZ-A
Sunspark	Where "YY" can be MX or ST; and "Z" can be M, MB, M3, M3B, P or W; and
	"A" can be 60 or 72

INSTALLATION GUIDE

## EcoFasten For Installers. By Installers.

VERSION: v1.3

REVISION DATE: 12/9/20

MANUFACTURER	LIST OF UL2703 APPROVED MODULES
Suntech	Suntech Modules with 35, 40 and 50mm frames
	STPxxxy-zz/aa
	Where "y" is blank or S; and "z"" can be 20, 24, A60 or A72U; and "aa" can be
	Vd, Vem, Vfw, Vfh, Wdb, Wde Wd, or Wfhb
	Talesun modules with 35 and 40mm frames
Talesun	TP6yZZaaxxx-b
	Where "y" can be blank, F, H, or L; "ZZ" can be 60 or 72; "aa" can be M, M(H),
	or P; and "b" can be blank, B, T, or (H)
	Trina Modules with 30, 35, 40 and 46mm frames
	TSM-xxxYYZZ
	Where "YY" can be DD05, DD06, DD14, DE14, DE15, DEG15, PA05, PC05,
Trina	PD05, PD06, PA14, PC14, PD14, PE14, or PE15 ; and "ZZ" can be blank, .05,
	.08, .10, .18, .08D, .18D, 0.82, .002, .00S, 05S, 08S, A, A.05, A.08, A.10, A.18,
	A(II), A.05(II), A.08(II), A.082(II), A.10(II), A.18(II), H, H(II), H.05(II), H.08(II),
	HC.20(II), HC.20(II), M, M(II), M.05(II), MC.20(II)
	URE modules with 35 mm frames
URE	
	Where "y" can be 6 or 7; "Z" can be K or M; and "aa" can be H3A, H4A, or
	Vikram solar modules with 40 mm frames
	VSw 77 AAA hh
Vikram	Where "wy" can be M_P_MBB_MH_MS_MHBB_or PBB: "77" can be 60 or 72:
	"AAA" is the module power rating: and "bb" can be 03.04 or 05
	VSUN modules with 35 and 40 mm frames
	VSUNxxx-YYz-aa
VSUN	Where "YY" can be 60, 72, 120, or 144; "z" can be M, P, MH, PH, or BMH; and
	"aa" can be blank, BB, or BW
	Waaree modules with 40mm frames
Waaree	WSyy-xxx
	where "yy" can be blank, M or MB
Winnigo	Winaico modules with 35 and 40 mm frames
	Wsy-xxxZa
winalco	Where "y" can be either P or T; "Z" can be either M, P, or MX; and "a" can be
	blank or 6
Yingli	Panda, YGE, YGE-U, and YLM series modules with 35, 40, and 50 mm frames